



Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
JK-SP/SS2***	YRS-370						KEJ-0.7 (plug) KEJ-0.4 (Socket)	
J-SP/SS1***	YRS-440	YC-440					DEJ-0.3	
J-SP/SS2***	YRS-330						DEJ-0.3	
LFO-1.0-250N						JUCS-FO		
LFO-2.5-250N						JUCS-FO		
MD-SP12**	YRS-470						MEJ-06	
MD-SP22**	YRS-460						MEJ-06	
RA-SC1290	YRS-231		YRM-232 YRM-233				EJ-RA	
RF-SC22**			YRM-230					
RPJ-SP/SS2331	YRS-331							
SAA-21(T)-**		YC-141						
SAA-50(T)-**		YC-182						
SAA-51(T)-**		YC-142						
SAB-51(T)-**		YC-142						
SACH-003G-P0.2	YRS-1190					WC-ACH2830		
SACHP-003G-P0.2						WC-ACH2830		
SACH-002GU-P0.3	YRS-858							
SAIT-A03T-M064A						WC-AIT03		
SAIT-A03GF-M064						WC-AIT03		
SAN-002T-0.8A SAN-002T-0.8K	YRS-220					WC-220	EJ-PH	
SAUH-001G-M0.2						WC-AUH001		
SBH-001T-P0.5		YC-670R				WC-670		
SBHL-002T-P0.5	YRS-857							
SBHM-001T-P0.5		YC-670R						
SBHS-002T-P0.5A	YRS-852						EJ-BHS2	
SBHSM-002T-P0.5	YRS-854							
SBHT-002T-P0.5	YRS-856 YRS-857							
SBN-001T-1.0	YRS-170	YC-170R						
SCN-001T-1.0K SCN-001T-P1.0	YRS-191					WC-191		
SCPT-A021GF-0.5	YRS-1310					WC-CPT021		
SCS-41T-2.3							CSJ-23	
SCZH-002T-P0.5	YRS-492							
SDF-01T-1.0A		YC-045						
SDF-01T-1.3AS		YC-045						
SDN-21T-P1.5		YC-600R						
SDY-01T-P1.6ASV		YC-525R					SLJ-1.4	
SEH-001T-P0.6	YRS-260	YC-260R				WC-260		
SF1F-002(*)-P0.6					YRK-1220	WC-SF1002	EJ-JFAJ1100	
SF1M-002(*)-M0.6A					YRK-1220	WC-SF1002	EJ-JFAJ1100	
SF1F-21(*)-P0.6					YRK-1210			
SF1M-21(*)-M0.6					YRK-1210			
SF3F-002(*)-P2.0				YRF-882	YRK-8821		EJ-JFAJ3	
SF3F-01(*)-P2.0				YRF-881	YRK-8811		EJ-JFAJ3	

Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
SF3M-01(*)-M2.0N				YRF-881	YRK-8811		EJ-JFAJ3	
SF3F-41(*)-P2.0				YRF-880	YRK-8801	WC-880	EJ-JFAJ3	
SF3M-41(*)-M2.0N				YRF-880	YRK-8801	WC-880	EJ-JFAJ3	
SF3F-71(*)-P2.0				YRF-1070	YRK-1071	WC-SF371	EJ-JFAJ3	
SF3M-71(*)-M2.0N				YRF-1071	YRK-1071	WC-SF371	EJ-JFAJ3	
SF0-41(T)-187N(8)		YC-271						
SF0-61(T)-250A		YC-270						
SFPS-61T-250		YC-272						
SFT-61T-250N		YC-510						
SGF-41(T)-4		YC-055						
SGF-51(T)-5		YC-065						
SGHD-002(*)-P0.2						WC-GH2630		
SGM-51(T)-4		YC-056						
SGM-51(T)-5		YC-056						
SGVH-002T-P0.2						WC-GH2630		
SGVHSF-002T-P0.2						WC-GVH2630		
SHCM-A03T-P025	YRS-960					WC-SHCM-A03		
SHF-001T-0.8BS	YRS-122	YC-122R				WC-122		
SHF-002T-0.8BS	YRS-300							
SHR-001T-P0.6	YRS-580	YC-580R						
SIM-01(T)-110A		YC-054						
SIM-1.0-250D/N						JUCS-IM		
SIM-2.5-250D/N						JUCS-IM		
SIM-41(T)-110B		YC-067						
SIM-51(T)-250N		YC-321						
SIN-001T-1.2	YRS-034							
SIN-002T-1.0S	YRS-035							
SIN-01T-1.2		YC-340R						
SIN-01T-1.8		YC-032						
SIN-01T-1.8N		YC-032						
SIN-21T-1.8		YC-350						
SIN-21T-1.8S		YC-570 (#20+22) YC-571 (#18)						
SIN-41T-2.4S		YC-561 (OD 2.2) YC-562 (OD 2.5)						
SIN-61T-2.6S		YC-560						
SIN-81T-3.6S		YC-940						
SJ1F-002GF-P0.8	YRS-8831							
SJ1F-01GF-P0.8	YRS-8841							
SJ2F-002GF-P1.0	YRS-8851				YRK-8851	WC-SJ2002	EJ-JFAJ2N	
SJ2M-002GF-M1.0N	YRS-8851				YRK-8851	WC-SJ2002	EJ-JFAJ2N	
SJ2F-01GF-P1.0	YRS-8861				YRK-8861	WC-SJ201	EJ-JFAJ2N	
SJ2M-01GF-M1.0N	YRS-8861				YRK-8861	WC-SJ201	EJ-JFAJ2N	
SJ2M-01GF-M1.0S	YRS-8861				YRK-8861		EJ-JFAJ2N	
SJ2F-21GF-P1.0				YRF-1120	YRK-1120	WC-SJ221	EJ-JFAJ2N	
SJ2M-21GF-M1.0N				YRF-1120	YRK-1120	WC-SJ221	EJ-JFAJ2N	
SJ3F-002GF-P1.8				YRF-882				
SJ3F-01GF-P1.8				YRF-881				
SJ3F-41GF-P1.8				YRF-880				
SJ4F-71GF-M3.0				YRF-1130			EJ-JFAJ4	
SJ4F-81GF-M3.0				YRF-1370			EJ-JFAJ4	
SJ5F-71GF-M6.5				YRF-888			EJ-JFAJ5	
SJ5M-71GF-M6.5				YRF-888			EJ-JFAJ5	

Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
SJ5F-81GF-M6.5				YRF-889			EJ-JFAJ5	
SJ5M-81GF-M6.5				YRF-889			EJ-JFAJ5	
SJ5F-91GF-M6.5							EJ-JFAJ5	
SJ5M-91GF-M6.5							EJ-JFAJ5	
SJN-001PT-0.9	YRS-1181							
SJN-002PT-0.9	YRS-036							
SLC-21T-2.0		YC-310				WC-310		
SLEB-001T-P0.2						WC-LEB001		
SLEH-001T-P0.15						WC-LEH001		
SLF/M-01T-P1.3E		YC-202	YRM-201			WC-202	LEJ-13	LIT-2013
SLF/M-41T-P1.3E		YC-203				WC-203	LEJ-13	
SLF/M-61T-2.0		YC-022						
SMF-01T-1.0		YC-081						
SMF-01T-1.3		YC-082						
SMM-003T-P0.5	YRS-800					WC-800		
SMR-001T-0.6	YRS-580	YC-580R					HRWJ	
SNAC-A081T-M2.8				YRF-1041				
SNAC3-A031T-M0.64					YRK-1011 YRK-1012			
SNSHD-003T-P0.2	YRS-859							
SOM-21(T)-187		YC-680						
SOM-51(T)-250		YC-066				WC-066		
SPA-001T-P0.5		YC-610R YC-611R					EJ-PH	
SPAL-001T-P0.5		YC-610R YC-611R				WC-610M	EJ-PAL	
SPAL-002T-P0.5	YRS-1340						EJ-PAL	
SPB-1.0-250N-S						JUCS-PB		
SPB-2.5-250N-S						JUCS-PB		
SPF-01T-2.5C		YC-043R						
SPH-001T-P0.5L	YRS-245					WC-244		
SPH-002T-P0.5L	YRS-241						EJ-PH	
SPH-002T-P0.5S	YRS-240		YRM-240			WC-240	EJ-PH	
SPH-004T-P0.5S	YRS-243						EJ-PH	
SPHD-001T-P0.5		YC-610R YC-611R				WC-610M	EJ-PHD	
SPHD-002T-P0.5	YRS-620		YRM-620			WC-620	EJ-PHD	
SPND-001T-C0.5	YRS-1091					WC-1091	EJ-PND	
SPND-002T-C0.5	YRS-1090					WC-1090	EJ-PND	
SPNI-001T-P0.5						WC-PNI001		
SPNI-002T-P0.5	YRS-1340							
SPS-01T-110		YC-740				WC-740		
SPS-01T-187(-8)		YC-730 YC-731				WC-730	EJ-PS187	
SPS-21T-205(-5)		YC-760						
SPS-21T-250		YC-780				WC-780	EJ-PS250	
SPS-21T-250S		YC-780				WC-780	EJ-PS250	
SPS-41T-110		YC-750 YC-751				WC-750		
SPS-51T-187(-8)		YC-710 #20-16 YC-711 #18-14				WC-710	EJ-PS187	

Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
SPS-51T-205		YC-770 #20-16 YC-771 #18-14						
SPS-61T-250		YC-720 #18-16 YC-721 #14				WC-720	EJ-PS250	
SPS-61T-250S		YC-720 #18-16 YC-721 #14				WC-720	EJ-PS250	
SPS-91T-250				YRF-790			EJ-PS250	
SPS-91T-250S				YRF-791			EJ-PS250	
SPSI-001T-M1.1		YC-335R						
SPSI-41T-M1.1		YC-225R						
SPUD-001T-P0.5	YRS-1320					WC-PUD1		
SPUD-002T-P0.5						WC-PUD2		
SRA-20(T)-*		YC-181						
SRA-21(T)-*		YC-141						
SRA-50(T)-*		YC-182						
SRA-51(T)-*		YC-142						
SRB-1.0-(*)						JUCS-RB/RT		
SRB-2.5-(*)						JUCS-RB/RT		
SRB-51(T)-**		YC-142						
SRC-01(T)-**		YC-033						
SRC-50(T)-**		YC-183						
SRC-51(T)-**		YC-142						
SRF-51(T)-**		YC-142						
SRT-1.0-(*)						JUCS-RB/RT		
SRT-2.5-(*)						JUCS-RB/RT		
SRT-51T-**		YC-143R						
SRWF-01GG-M0.6							EJ-RPZ	
SRWM-01GG-S0.6							EJ-RPZ	
SRWF-21GG-M0.6							EJ-RPZ	
SRWM-21GG-S0.6							EJ-RPZ	
SRWF-61GG-M0.6		YC-840R					EJ-RPZ	
SRWM-61GG-S0.6		YC-840R					EJ-RPZ	
SSH-003T-P0.2H	YRS-859					WC-SH2832		
SSH-003GA-P0.2	YRS-859					WC-SH2832		
SSHL-002T-P0.2	YRS-1590					WC-GH2630		
SSHL-003T-P0.2	YRS-859					WC-SH2832		
SSHL-003GA1-P0.2	YRS-859					WC-SH2832		
SSFH-001T-P0.5						WC-SFH1		
SSFH-002T-P0.5	YRS-1490					WC-SFH2		
SSF/M-01T-P1.4		YC-500					SLJ-1.4	ITBL-08V
SSF/M-21T-P1.4		YC-550				WC-550	SLJ-1.4	
STI-01(T)-110N		YC-041						
STI-1.0(T)-250D/N						JUCS-TI		
STI-2.5(T)-250D/N						JUCS-TI		
STI-41(T)-110N		YC-063						
STI-51(T)-250N		YC-322						
STO-01(T)-110N(-8)		YC-041						
STO-01(T)-187N(-8)		YC-042						
STO-0.25-110N		YC-810						
STO-0.5-110N		YC-820				JUCS-05110		
STO-1.0-110N						JUCS-2.8/4.8		

Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
STO-1.0-187N						JUCS-2.8/4.8		
STO-1.0(T)-250N						JUCS-6.3		
STO-2.5(T)-250N						JUCS-6.3		
STO-21(T)-205N		YC-053						
STO-21(T)-250N		YC-102						
STO-41(T)-110N(-8)		YC-062						
STO-41(T)-187N(-8)		YC-051						
STO-41(T)-187S		YC-064						
STO-61(T)-250N		YC-047						
STO-81(T)-250N		YC-280		YRF-280				
STS/D-002GG-P0.6	YRS-1360							
SVA-41T-P1.1		YC-450					EJ-SMP	
SVF-01T-1.5A		YC-044						
SVF-01T-1.5N		YC-151						
SVF-01T-2.36N		YC-152					EJ-LV	
SVF-42T-P2.0		YC-592				WC-592	VLJ-20	
SVM-42T-P2.0		YC-593				WC-592	VLJ-20	
SVF/M-61T-P2.0				YRF-590		WC-590	VLJ-20	
SVF/M-81T-P2.0				YRF-591		WC-591	VLJ-20	
SVH-21T-P1.1		YC-160R YC-161R YC-164R	YRM-160 - YRM-164			WC-160	EJ-NV	
SVH-41T-P1.1		YC-930R YC-931R				WC-930	EJ-NV	
SVT-41T-P1.1		YC-630					EJ-VT	
STU-21T-P0.6		YC-990R					EJ-VU4	
SVYF-61T-P0.5A				YRF-536				
SWPJT-21T-P0.5						WC-WPJM	EJ-WPJ	
SWPJT-21T-P0.5A						WC-WPJ(A)	EJ-WPJ	
SWPJR-21T-M0.5						WC-WPJM	EJ-WPJ	
SWPJR-21T-M0.5A						WC-WPJ(A)	EJ-WPJ	
SWPKP-21T-0.6				YRF-1051				
SWPKR-21T-0.6				YRF-1050				
SWPR-001T-P025	YRS-980					WC-JWPF	EJ-JWPF	
SWPT-001T-P025	YRS-980					WC-JWPF	EJ-JWPF	
SXA-01T-P0.6	YRS-701	YC-701R				WC-700M	EJ-XMP	
SXM-01T-P0.6	YRS-701	YC-701R					EJ-XMP	
SXA-001T-P0.6	YRS-692	YC-692R				WC-692	EJ-XMP, EJ-XMR	IT-XA
SXM-001T-P0.6	YRS-692	YC-692R					EJ-XMP, EJ-XMR	IT-XA
SXA-001T-P0.6L	YRS-691					WC-691		
SXAM-01T-P0.6	YRS-701	YC-701R				WC-700M		
SXAM-001T-P0.6	YRS-692	YC-692R				WC-692		
SXF-01T-P0.7		YC-251					LEJ-7	
SXF-41T-P0.7		YC-252					LEJ-7	
SXH-001T-P0.6	YRS-110	YC-110R YC-111R				WC-110	XJ-06	
SXH-001T-P0.6N	YRS-110					WC-110	XJ-06	
SXH-002T-P0.6	YRS-480						XJ-06	
SXNI-001T-P0.6	YRS-1380							
SXNI-003T-P0.6	YRS-1390							
SYF-001T-P0.6	YRS-125							
SYF/M-01T-P0.5A		YC-520				WC-520	YLJ-0.5	
SYF/M-41T-P0.5A		YC-530				WC-530	YLJ-0.5	
SYF-61T-P0.5A				YRF-536				
SYM-001T-P0.6	YRS-121	YC-121R				WC-121	SMJ-06	
SYM-01T-P0.7		YC-251					LEJ-7	
SYM-41T-P0.7		YC-252					LEJ-7	

Terminal Number	HANDTOOL						Extraction Tool	Insertion Tool
	YRS Series	YC Series	YRM Series	YRF Series	YRK,YRK-EX Series	WC Series		
SZE-002T-P0.3	YRS-1460 (AWG 24, 26 +28)					WC-ZE2426 (AWG 24+26)		
SZE-003T-P0.3	YRS-1330							
SZF/M-01T-P0.7		YC-390R					ZLJ-07S	
SZF/M-41T-P0.7		YC-380R					ZLJ-07S	
SZH-002T-P0.5	YRS-491					WC-491 WC-ZH2632		
SZH-003T-P0.5	YRS-490					WC-490 WC-ZH2632		
SZN-002T-P0.7K	YRS-541							
SZN-003T-P0.7K	YRS-540							
SZPD-002T-P0.3	YRS-1460 (AWG 24, 26 +28)					WC-ZE2426 (AWG 24+26)		